

Marcel Pom-Chips—Didier Ferment


Instructions

Use a Chips (or Crisps) bag made of "aluminium" mylar or thick plastic in order to obtain a rigid "sail". If you use different chips bag, except bacon ones, you must calculate new dimensions in proportion. Nevertheless, turn down small bags and short ones: the length must be 25% as long as the width.

The 2 spars are bamboo (or wood) sticks for skewers: diameter 2-3 mm.

You need tape and sewing thread too.

- A. Circumference = 38 cm
- B. The transversal stick of the front of the kite is taped at its 2 tips.
- C. Stick length = 13.5 cm.
- D. Bag length = 26 cm.
- E. Distance = 10 cm.
- F. Distance of the main line from the front = 5 cm. Strengthen the fixing by tape.
- G. Line of the kite made of sewing thread.
- H. The longitudinal stick inside the kite is taped at its 2 tips.
- I. You can add a tail 2-3 meter long at this point. Use thin carrier bag (food-market bag) that you cut into strips 3-5 cm width.
- J. The end of the bag is open.



Fly in wind 2 to 6 Beaufort strength.
You may need an assistant for the take off.

If your kite turns, check for creases of the "sail"; otherwise, add a tail.

Happy Flying !